

## WLAN adapter integrated in the unit

- CTXA-AW
- CTXA-BS
- CTXA-BT
- CTXA-BB
- FTXA-AW
- FTXA-BS
- FTXA-BT
- FTXA-BB
- CTXM-R
- FTXM-R
- CVXM-R
- FVXM-A
- ATXM-R
- FTXJ-AW
- FTXJ-AS
- FTXJ-AB
- FTXTA-BW
- FTXTA-BB
- FTXTM-R
- FTXTP-M

## BRP069B41

- FTXM-M
- CTXM-M
- ATXM-M
- FTXTM-M
- BRP069A45
- FTXG-LS
- FTXG-LW
- FTXJ-MW \*
- FTXJ-MS \*

\* controller included with the unit

## BRP069B42

- FTXZ-N
- FTXS35-42-50K
- FTXS60-71G
- FTX50-60-71GV
- FTXLS-K3
- FVXG-K
- FVXS-F
- FLXS-B
- FLXS-B9
- ATXS35-50K
- FVXM-F

## BRP069B43

- CTXS15-35K
- FTXS20-25K
- FTX20-25-35J3
- FTXL-JV
- ATXS20-25K
- ATX-J3
- ATXL-JV

## BRP069B45

- FTX20-25-35KV
- FTX50-60KV
- ATX-KV
- FTXP-L
- ATXP-L
- FTXF-A
- FTXTP-K
- ATXTP-K

## BRP069A61/62

Daikin Altherma GEO

- **EGSQH-A9W**

Daikin Altherma 3 GEO

- **EGSA(H/X)-D9W**

Daikin Altherma H Hybrid

- **EHY2KOMB-A**

Daikin Altherma R Hybrid

- **EHYHB(H/X)-AV3(2)**

Daikin Altherma R

- **EBBH(X)-CB**
- **EHVH(H/X/Z)-CB**

Daikin Altherma 3 R

- **EBH(H/X)-D**
- **EHV(H/X/Z)-D**
- **EHF(H/Z)-D**

Daikin Altherma 3 H

- **EAB(H/X)-D**
- **EAV(H/X/Z)-D**

Daikin Altherma 3 H HT

- **ETB(H/X)-D**
- **ETV(H/X/Z)-D**

Daikin Altherma M

- **EBLQ-CV3**
- **EDLQ-CV3**

## BRP069A71

Daikin Altherma 3 R (option)

- **EBH(H/X)-E**
- **EHV(H/X/Z)-E**

## BRP069A78

Daikin Altherma 3 R

- **EBH(H/X)-E**
- **EHV(H/X/Z)-E**

Daikin Altherma 3 M (option)

- **EBLA09-16D(3)V3/W1**
- **EDLA09-16D(3)V3/W1**

## BRP069A81\*\*

Ceiling mounted

- **FFA-A9**

Concealed ceiling

- **FDXM-F9**
- **FBA-A(9)**
- **FDA125A**
- **ADEA-A**

Wall mounted

- **FAA-A**

Ceiling suspended

- **FHA-A(9)**
- **FUA-A**

Floor standing

- **FVA-A**
- **FNA-A9**

## BRP069B82\*\*

Ceiling mounted

- **FCAHG-H**
- **FCAG-B**
- **FDA200-250A**

## BRP069C51\*\*

Ceiling mounted

- **FXFA-A**
- **FXZA-A**

Concealed ceiling

- **FXDA-A**
- **FXSA-A**

Concealed ceiling

- **FXAA-A**

## DRGATEWAYAA

- **D2CND-A1A**
- **D2CND-A4A**
- **D2CND-A5A**
- **D2HND-A5A**
- **D2TND-A4A**

\*\* Wired remote controller must be connected to the indoor unit to operate online controller